



Description

The PRC5500 Passive Room Coupling Unit allows coupling of two conference rooms.

Coupling can be done from a key switch placed at the front of the panel. When the key switch is in the slave position, there will be a physical connection between the two rooms connected to the PRC5500 unit. The floor channel in both rooms will be shared.

This unit allows a passive coupling. Therefore, only the interpreter channels from the master room will be shared by the two rooms.

Turning the switch in the local master position will disconnect the rooms.

Features and Control

- 2 position key switch: 'Local Master' and 'Slave' position
- Green 'Slave' LED

Specifications

Technical Data	
Dimensions	43x483x285 mm
Weight	Approx. 3.2 kg
Colour	Matt Black
Housing	Metal
Part Number	71.61.5055

Connectivity

- Two 8-pin RJ45 connectors for connection to CE5500 Master room (TMS & Clock)
- Two 8-pin RJ45 connectors for connection to CE5500 Slave room (TMS & Clock)
- One Phoenix power supply connector (48 V DC in)
- Two 8-pin RJ45 connectors for connection to Slave room Extension Units (TMS & Clock)